




INSTALLATION INSTRUCTION


The installation and maintenance of this product must be by a professional. Please read this instruction sheet carefully before installation.



Do not operate with power supply connected.


CE Voltage: AC~220V~240V
Frequency: 50Hz

1.




POWER OFF

2.



3.



POWER ON

- Make sure the power supply is switched off before maintenance.
- Please respect all fireproofing legislation.
- This product should not be covered with combustible material.

